

1. Please be careful to use only firewood made of hard wood for your fireplace. Free firewood is available near the lakeshore sauna or under the shed in the centre of the holiday village.
2. Please use either birch bark or special tablets for kindling. The use of kindling liquid is not allowed.
3. For kindling,
 - a. place the firewood inside in the correct way.
 - b. Open the valve on the pipe by pulling the lever all the way until it stops.
 - c. Make sure that the air regulator is set in the extreme right position. The regulator is located on a horizontal plane between the glass door top and the shelf.
 - d. Open the ash drawer or move the air regulator on it to an open position.
4. Control the speed of the firewoodburning by positioning the valve on the pipe and the regulator on the ash drawer.
5. If the coals from the fireplace should fall to the floor, remove them immediately with the dustpan and brush standing next to the fireplace.

Attention! If smoke is coming from the fireplace into your room,

- a. check if the valve on the pipe is open
- b. and whether the cooker hood (which changes the air circulation in the house) is switched off.
- c. when kindling the fireplace in the cold season, leave the door to the terrace ajar and close it when the firewood is kindled and the chimney warms up.