

Each cottage offers a sauna with electric *HARVIA* heating stove. The heating stove has 2 regulators: power-on and late start timer and thermostat for temperature setting.




Figure 2. Timer Switch




Figure 3. Thermostat Switch

STARTING THE HEATING STOVE:

1. Set the thermostat (Fig. 3) for the maximum position.
2. Set the timer switch for the position 1-4 on the white scale (Fig. 2, scale A).
3. The heating stove will start warming.
4. In 40 minutes, the temperature in the sauna may reach 60-70°C.

LATE START SETTING:

Set the timer switch for the position 1-8 on the dark scale (Fig. 2, scale B). As soon as the timer sets the switch for the On position, the heating stove will start working. After that, the heater will continue working for about four hours.

Example: You wish to use the sauna after a three-hour walk. Set the timer switch for number 2 in Late Start zone. The timer will start out. In two hours, the heating stove will start working. Since it takes about an hour for the heater to warm up, the sauna will be ready by the time you come back from your walk, or in about three hours.

TURNING THE HEATING STOVE OFF:

The heating stove turns off, when the timer sets the switch for the zero position. To manually switch the heater off at any time, set the timer switch for the zero position.

The heating stove must be turned off after using the sauna.

Attention! When the sauna heating stove is on, the heating system of the cottage turns off automatically.

Remember to switch off the sauna heating stove, when you leave the cottage or go for long trips.